

Task 1

$$T = 10 \log_{10} \left(\frac{P}{1 \text{ mW}} \right) \text{ dBm} \quad - \text{the reading of detector B}$$

$$P = 10^{\frac{T}{10 \text{ dBm}}} \text{ mW}$$

$$P_{\min} \rightarrow T_{\min}; T < 0$$

We cover the emitter A with 2-3 layers of aluminum foil until the detector displays "----". Then, we try to unfoil the emitter little by little until the detector (B) can measure the value. We repeat the experiment at least 10 times.

Number	T_{\min} (dBm)
1	-107
2	-106
3	-114
4	-108
5	-125
6	-110
7	-103
8	-113
9	-120
10	-105 -117

→ The minimum recorded:

$$T_{\min} = -12.5 \text{ dB}$$

$$P_{\min} = 10^{\frac{T_{\min}}{10 \text{ dBm}}} \text{ mW}$$

$$\Rightarrow P_{\min} = \frac{3.16}{3.98} \cdot 10^{-13} \text{ mW}$$



Student: ROU-S2

Sheet: E-001

Side: B

Task 2 3

$$\vec{E} = \vec{E}_0(r, \varphi) e^{-ik_2 z - i(\omega t)}$$


$$P_d |\vec{E}|^2 \Rightarrow P_d |E_0(r, \varphi) e^{-ik_2 z - i(\omega t)}|^2$$

$$P_d E_0^2(r, \varphi) |e^{-ik_2 z - i(\omega t)}|^2$$

$$|e^{-ik_2 z - i(\omega t)}|^2 = \cos^2(\omega t - k_2 z) + \sin^2(\omega t - k_2 z) = 1$$

$$\Rightarrow P_d E_0^2(r, \varphi) e^{-2k_2 z} \quad (1)$$

First, we place the empty tube D horizontally and measure the received power (as γ in dBm) in air ($d=0$).



We reconstruct the setup

10 times and measure γ_{air} .

We take care to align the system correctly and hold the emitter parallel with the tube, which is wrapped tightly with aluminium foil (F) and taped. The upper end is also wrapped (with the emitter), to prevent the leaking of the signal in the wrong direction.



# Nr.	\bar{J}_{air} (dBm)
1	-58
2	-60
3	-62
4	-59
5	-60
6	-61
7	-57
8	-55
9	-59
10	-60

$$\Rightarrow \bar{J}_{air} \approx -59.1 \text{ dBm}$$

Now, we put water into the tube, and measure the height with the stick Q (introducing the stick until we hit the bottom of the tube D and measuring with the ruler H the wet region). For each z (cm), we measure 10 times $J(z)$ with the detector.

$z = 8.4 \text{ cm}$:	#	$J(z)$ (dBm)
	1	-62
	2	-63
	3	-64
	4	-60
	5	-61
	6	-63
	7	-61
	8	-62
	9	-62
	10	-63

$$\Rightarrow \bar{J}(z) \approx -62.1 \text{ dBm.}$$



Student: ROU-S2

Sheet: E-002

Side: B

$$\underline{Z = 17.1 \text{ cm}}$$

#	$\bar{Y}(Z)$ (dBm)
1	-66
2	-65
3	-70
4	-62
5	-62
6	-63
7	-65
8	-66
9	-64
10	-65

$$\Rightarrow \bar{Y}(Z) = -64.8 \text{ dBm}$$

$$\underline{Z = 25.0 \text{ cm}}$$

#	$\bar{Y}(Z)$ (dBm)
1	-68
2	-72
3	-71
4	-65
5	-66
6	-67
7	-68
8	-67
9	-71
10	-66

$$\Rightarrow \bar{Y}(Z) = -68.1 \text{ dBm}$$



$$\underline{Z = 33.7 \text{ cm}}$$

#	$\gamma(Z)$
1	-71
2	-75
3	-73
4	-70
5	69
6	69
7	68
8	72
9	73
10	70

$$\Rightarrow \bar{\gamma}(Z) = -71.0 \text{ dBm.}$$

$$\underline{Z = 42.5 \text{ cm}}$$

#	$\gamma(Z)$
1	-73
2	-69
3	-74
4	-74
5	-73
6	-72
7	-75
8	-74
9	-74
10	-73

$$\Rightarrow \bar{\gamma}(Z) = -73.1 \text{ dBm}$$

$$(1) \Rightarrow P = P_0 e^{-2\alpha Z} \quad \left. \begin{array}{l} \frac{\gamma(Z)}{10 \text{ dBm}} \\ \frac{\gamma_{air}}{10 \text{ dBm}} - 2\alpha Z \end{array} \right\} \Rightarrow 10 = 10 \cdot e^{-2\alpha Z}$$

$$P = 10 \frac{\text{mW}}{\text{dBm}}$$



Student: ROU-S2

Sheet: E-003

Side: B

$$\lg\left(\frac{I(2)}{10 \text{ dBm}}\right) = \lg\left(\frac{I_{air}}{10 \text{ dBm}}\right) - 2d^2$$

$$\frac{I(2)}{10 \text{ dBm}} \lg 10 = \frac{I_{air}}{10 \text{ dBm}} \lg 10 - 2d^2$$

$$\Rightarrow \frac{I(2)}{10 \text{ dBm}} = \frac{I_{air}}{10 \text{ dBm}} - \frac{2d}{\lg 10} = 2$$

We plot $\frac{I(2)}{10 \text{ dBm}} = a + b^2$ and find $b = \frac{2d}{\lg 10}$


$$\Rightarrow d = \frac{\lg 10}{2} \cdot b \quad (\text{Plot E-016 A})$$

$$b = \frac{-1.25}{42.5 - 2.5} \text{ cm}^{-1}; b \approx 3.13 \cdot 10^{-2} \text{ cm}^{-1}$$

$$\Rightarrow d = 3.60 \cdot 10^{-4} \text{ m}^{-1}$$

Task 4a

We place the tube C horizontally and the detector at one of its ends. We place the emitter right next to the detector and push the emitter inside the tube with the stick Q a desired length (measured with the ruler on the stick and marked on the stick). We collect 5 data for each z and find $P(z)$ from $I(z) = 10 \log_{10}\left(\frac{P}{1 \text{ mW}}\right) \text{ dBm}$.



$$z = z_{\text{ruler}} + \Delta z$$

$$\Delta z = 6 \text{ mm}$$

$z(\text{cm})$	$T(z) (\text{dBm})$	$\bar{T}(z) (\text{dBm})$
2	-36 -35 -35 -36 -36	-35.6
3	-45 -45 -44 -46 -45	-45.0
4	-51 -51 -51 -52 -50	-51.0



Student: ROU-S2

Sheet: E-004

Side: B

Z (cm)	$T(2)$ (dBm)	$T(2)$ (dBm)
5	-61 -61 -61 -61 -61	-61.0
6	-71 -72 -72 -71 -71	-71.4
7	-81 -82 -81 -81 -82	-81.4
8	-90 -91 -90 -90 -89	-90.0
9.	-97 -97 -98 -97 -97	-97.2
10	-106 -105 -106 -105 -105	-105.4.



z (cm)	$\bar{Y}(z)$ (dBm)	$\bar{Y}(z)$ (dBm)
11	-114	
	-114	
	-115	
	-114	
	-114	

-114.2

$$\bar{Y}(z) = Y_0 - \mu_0 z$$

Let's plot $\bar{Y}(z)$ (z) on E-016 B.

$$\text{From plot} \rightarrow -\tan\phi = \mu_0 = \frac{7.9 \text{ dBm}}{9 \text{ cm}} ; \mu \approx 8.78 \text{ dBm/cm}$$

$$\cancel{P(z)} = 10^{\frac{Y_0 - \mu_0 z}{10 \text{ dBm}}} \text{ mW}$$

$$\cancel{P(z)} = P_0 \cdot 10^{-\frac{\mu_0 z}{10 \text{ dBm}}} \text{ mW}$$

$$\cancel{P(z)} = P_0 \cdot 10^{-\frac{\mu z}{10 \text{ dBm}}} \text{ mW}$$

$$\mu \approx 8.78 \frac{\text{dBm}}{\text{cm} \cdot \text{mW}}$$

$$P(z) = 10^{\frac{Y_0 - \mu_0 z}{10 \text{ dBm}}} \text{ mW.}$$

$$P(z) = P_0 \cdot 10^{-\frac{\mu_0 z}{10 \text{ dBm}}} \text{ mW}$$

$$P(z) = P_0 \cdot 10^{-\frac{\mu z}{10 \text{ dBm}}} \text{ mW}$$

$$\mu \approx 0.88 \text{ cm}^{-1}$$



Student: ROU-S2

Sheet: E-005

Side: B

Task 4b

We repeat the measurements from 4a using different tubes.

$$d_2 = 46 \text{ mm} :$$

$z \text{ (cm)}$	$\gamma(z) \text{ (dBm)}$
2	-33
3	-40
4	-48
5	-55
6	-63
7	-71
8	-81
9	-88
10	-96
11	-105

Plot E-017 A:

$$\gamma = \gamma_0 - \mu_{2,0} z$$

$$\Rightarrow \mu_{2,0} = \frac{65 \text{ dBm}}{8 \text{ cm}} = 8.13 \text{ dBm/cm}$$

$$\Rightarrow \mu_2 \approx 0.81 \text{ cm}^{-1}; P_2(z) = P_0 e^{-\mu_2 z}$$

$$d_3 = 59 \text{ mm} :$$



$Z(\text{cm})$	$\gamma(Z) (\text{dBm})$
2	-33
3	-41
4	-45
5	-50
6	-57
7	-63
8	-69
9	-76 -77
10	-84
11	-91

$$\gamma = \gamma_0 - \mu_{30} Z$$

$$P_3(Z) = P_0 e^{-\mu_3 Z}$$

Plot E-017B:

$$\mu_{30} = \frac{62 \text{ dBm}}{9 \text{ cm}} = 6.89 \text{ dBm/cm}$$

$$\mu_3 = 0.69 \text{ cm}^{-1}$$

$d_L = 100 \text{ mm}$:

$Z(\text{cm})$	$\gamma(Z) (\text{dBm})$
2	-27 -33
3	-36
4	-39
5	-43
6	-47
7	-50
8	-53
9	-56
10	-59
11	-63



Student: ROU-S2

Sheet: E-006

Side: B

$$I = I_0 e^{-\mu_0 z}$$

$$P_d = P_0 e^{-\mu_0 z}$$

Plot E-018 A: $\mu_{h0} = \frac{30 \text{ dBcm}}{9 \text{ cm}} \approx 3.33 \text{ dBcm/cm}$

$$\mu_h \approx 0.33 \text{ cm}^{-1}$$

$d(\text{cm})$	$\mu(d) (\text{cm}^{-1})$	$\ln d$	$\ln \mu$
4.1	0.88	1.41	-0.13
4.6	0.81	1.53	-0.21
5.9	0.69	1.77	-0.37
10.0	0.33	2.30	-1.17

Let it be ~~$\mu(d) = \alpha d^\beta$~~

$$\ln \mu = \ln \alpha + \beta \ln d$$

Plot E-018B: $\Rightarrow \beta \approx -1.5 ; \ln \alpha \approx 2.00$
Linear regression.

$$\Rightarrow \mu(d) = \alpha d^{-1.5} ; \alpha \approx 7.3 \text{ cm}^{1/2}$$


$$\Rightarrow \mu(d) = 7.3 d^{-1.5} , \mu \text{ in cm and } d \text{ in cm.}$$

$$\text{Or, } \mu(d) = 7.3 \text{ cm}^{1/2} d^{-1.5}$$




Task 2

We construct the setup from fig 2 and place the detector on the top of the box E, rotating the superior (detachable) wall of the box by $\frac{\pi}{2} \cdot \frac{\pi}{2}$.




top view



Side view

h - height of water

B $\gamma(h)$



We fill the box with water little by little and measure $\gamma(h)$.

We can measure h with the stick Q and the ruler H, or just with ruler H.



Student: ROU-S2

Sheet: E-007

Side: B

h (cm)	$\gamma(h)$	dBm
0.0	-52	
0.8	-37	
1.2	-46	
1.4	-49	
1.5	-50	
1.6	-51	
2.0	-49	
2.5	-46	
2.9	-37	
3.1	-41	
3.2	-45	
3.4	-47	
3.6	-51	
3.8	-50	
4.0	-47	
4.2	-46	
4.4	-43	
4.6	-42	
4.8	-39	
4.9	-38	
5.0	-39	
5.1	-42	


See $\gamma(h)$ in plot E-019 A



We notice the periodic $\gamma(h)$ with

$$\Delta h \approx 2 \text{ cm}.$$

$$\Delta h = \frac{\lambda_w}{2} \Rightarrow \lambda_w = 2\Delta h, \quad \lambda_w \approx 4 \text{ cm}$$



Task 5

$$\lambda_{\text{water}} = m \lambda_{\text{air}}$$

$$m = \frac{\lambda_{\text{water}}}{\lambda_{\text{air}}} ; \quad \lambda_{\text{air}} \approx 3 \text{ cm}$$

$$m = 1.33$$

Student: ROU-S2

Sheet: E-016

Side: A




tanR3

10 cm
10 cm

A

10 cm



tanR3




Student: ROU-S2

Sheet: E-016

Side: B

Task 4a



Student: ROU-S2

Sheet: E-017

Side: A



Tank 4b

$d_2 = 46 \text{ mm}$

A 100 cm

20 cm

0 1 2 3 4 5 6 7 8 9 10 11

10 11 12 13 14 15 16 17 18 19 20

21 22 23 24 25 26 27 28 29 30

31 32 33 34 35 36 37 38 39 40

41 42 43 44 45 46 47 48 49 50

51 52 53 54 55 56 57 58 59 60

61 62 63 64 65 66 67 68 69 70

71 72 73 74 75 76 77 78 79 80


81 82 83 84 85 86 87 88 89 90

91 92 93 94 95 96 97 98 99 100

101 102 103 104 105 106 107 108 109 110

111 112 113 114 115 116 117 118 119 120

121 122 123 124 125 126 127 128 129 130






Student: ROU-S2

Sheet: E-017

Side: B



Student: ROU-S2

Sheet: E-018

Side: A




Task 4 b

$d_L = 100 \text{ mm}$

$\Gamma(\lambda) (\text{dBm})$

$\Gamma(\text{cm})$





Student: ROU-S2

Sheet: E-018

Side: B

thank you!

Graph of $P = P_0 e^{-\rho z}$

$$P = P_0 e^{-\rho z}$$

$$\ln(P) = -\rho z + \ln(P_0)$$

$$\frac{\ln(P)}{z} = -\rho + \frac{\ln(P_0)}{z}$$

$$\text{Slope } m = -\rho$$

$$\text{Y-intercept } b = \ln(P_0)$$

$$\ln(P_0) = b$$

$m = \text{dil.}$

Student: ROU-S2

Sheet: E-019

Side: A

